

MIRROR A PART

* CREATE AN ASSEMBLY FOR A PART REFERENCE

*  INSERT PART

* WHEN SETTING THE "COMPONENT PLACEMENT"
USE DATUM PLANES:

ASSEMBLY TOP → PART TOP

ASSEMBLY FRONT → PART FRONT

ASSEMBLY SIDE → PART SIDE SET 30"
OFF ASSEMBLY SIDE

